

DevaFuser Directions

For each DevaFuser position shown below, slightly tilt the DevaFuser for 360 degree air flow.

- 1 Set button to desired temperature setting.
- 2 Set speed to high or low.
- 3 Tilt head gently guiding the DevaFuser onto the scalp and in the nape area. (Directly behind the ear.)
- 4 Hold for 2 minutes in this position to evaporate moisture and to begin setting the curl. (Repeat the same process on the other side.)
- 5 Place the DevaFuser on the scalp in the temple region. (Above the ear.)
- 6 Hold for 2 minutes in this position to evaporate moisture and to begin setting the curl. (Repeat the same process on the other side.)



NEW! Deva Clips

For Deva Clip users, place the DevaClips and follow the instructions above while clips are in hair.

Professional use



Self use



For additional drying and extra volume, guide the DevaFuser onto the forehead region and tilt the dryer upward.

To dry the mid length of the hair, position the DevaFuser in between the bulk of hair so that it will dry inside and outside simultaneously.